


# FCT-114DS

## Photo/Visual System Chart


### ▼ Standard Accessories

- 13. 50.8 Sleeve [TKP00113]
- 14. Coupling (S) [TKP00103]
- 46. Eyepiece Adapter (31.7) [TKP00101]
- 50A. M72 Extension Tube L52 [TKA23250]
- 70S. 50.8 Adapter [TKP27110S]
- 71L. Extension Tube (L) [TKP31112]



### ▼ Optional Accessories

- 6M. Camera Angle AdjusterM [TKA23200N]
- 17. M72-M55.9 Coupling L5 [TKA34201]
- 18T. FCT-L Reducer 0.8x [TKA34580]
- 18. FC-35 Reducer 0.66x [TKA19580]
- 30M. CA Ring 102 [TKA23202]
- 30A. M72-M48 CMOS Adapter [TKP00200]
- 30B. M72-M54 CMOS Adapter [TKA00201]
- 30C. M72 WR Adapter [TKA00202]
- 33. Camera mount DX-WR (EOS) [TKA01251]  
Camera mount DX-WR (Nikon) [TKA01255]
- 34. DSLR
- 35. CA-35 (50.8) [TKA31201]
- 47. Eyepiece 31.7
- 48. Eyepiece 50.8
- 49. Prism Diagonal 31.7 [TKA00547]
- 52M. FCT-L C0 Ring 114D [TKA34200]
- 74. Mirror Diagonal 50.8 [TKA00543]
- 75. Adapter 31.7 (DM) [TKA00111]
- 80T. FCT-L Flattener 0.99x [TKA34582]
- 80N. FC/FS Multi Flattener 1.04 [TKA00582]
- 88L. Multi CA Ring 100 [TKA19203]
- 93. CMOS (M48 P=0.75 Female, Metal back/Back Focus = 55mm)
- 94. CMOS (M54 P=0.75 Female, Metal back/Back Focus = 55mm)



TAKAHASHI